

10 GigE Cameras with Baumer GAPI SDK

AN201802/1.0/2021-10-07

Description

Starting with the Version 2.9.0, the Baumer GAPI SDK also supports cameras with 10 GigE interface according to IEEE802.3an (10GBase-T Copper) and IEEE802.3ae (Fiber Optic).

However, the utilized PC system must support the increased bandwidth of the 10 GigE Interface. If the PC system is not capable to support the increased bandwidth, it will result in dropping packets and corrupted images.

This application note describes Baumer-tested PC systems for 10 GigE cameras in combination with Baumer GAPI SDK. It describes possible root causes and provides troubleshooting tips to configure a system successfully.



Products

Baumer cameras with 10 GigE interface

Contents

1	Recommended PC Systems	2
1.1	Hardware	2
1.2	Operating System	2
1.3	Recommended System Configuration	2
1.4	Camera Explorer Image and Packet Statistics View	3
1.5	Possible Reasons for Lost Packets	3
1.6	Resend Algorithm – Network Advice	4
1.7	Resend Algorithm – Configuration	4
1.8	Further Configuration and Optimization	6
2	Related Topics	7
3	Support	7
4	Legal information	7

1 Recommended PC Systems

The Baumer GAPI SDK is tested with two 10 GigE cameras operating at maximum bandwidth and utilizing the Baumer Filter Driver. The acquired images are displayed by the Camera Explorer. Besides display, no other background operations, such as third party software, Antivirus software or any user interaction, are executed on the PC.

Notice

For optimal performance on Windows Systems it is strongly recommended utilizing the included Baumer Filter Driver.

1.1 Hardware

Baumer considers the hardware that is used for these tests to be the minimum recommended configuration:

CPU	Intel® Core™ i7-7820X (8 Cores, 3,6 GHz)
RAM	2 x 16 GB RAM (Dual-Channel)
NIC	Intel(R) Ethernet Converged Network Adapter X550-T2

The test described in paragraph 1 causes a load of around 15% on the above-mentioned PC system.

Since additionally to image acquisition and display, processes like image processing have to run on the system, a significantly more powerful system might be required.

1.2 Operating System

Baumer recommends the 64 bit operating systems Windows 7 and Windows 10 (including the latest patches) as well as all modern Linux variants.

1.3 Recommended System Configuration

The process of image acquisition depends on parameterization as well as processes running in parallel. In the event of corrupted images, check the following configuration parameters:

Parameter		Recommended action
Windows OS / Firewall		deactivate if necessary
Windows OS / Defender Antivirus		deactivate if necessary
Windows OS / Power Profile		set to high performance
Network Settings / Paket Size		set to maximum
Network Settings / Jumbo Frames		set to maximum
Network Settings / Receive Buffer Count		set to maximum
Baumer GAPI / <i>bsysgige.xml</i>	Streaming via socket driver	set StreamSocketSize to 64 MB
	Streaming via filter driver	set FilterDriverBufferCount to 50.000
	MaxResendsPerPacket	set to 44
	ResendRetryTreshold	set to 100

1.4 Camera Explorer Image and Packet Statistics View

The Camera Explorer provides statistics information in the info view. You can use this view to check the stability of the image stream.




Figure 1: Camera Explorer Network Statistics Info View

1.5 Possible Reasons for Lost Packets

In a typical camera system no packet should be lost in the network as vision networks are usually rather small and separated. If packets are lost in the network we recommend to rework the system so the issue can be mitigated. We consider such a network as not fit for purpose for machine-vision applications.

The most common cause for lost packets is that packets which are received correctly by the Ethernet stack are filling up the available packet queues as they are not retrieved by the software quickly enough. If a packet queue is filled up all further incoming packets must be discarded by the Ethernet stack.

If the packet queues are filled up over longer periods it is likely that the PC system is not powerful enough for the given application.

However, even on a very powerful PC system, just a short interruption of receiving application can fill the packet queues and lead to dropped (missing) packets. In those cases the resend algorithm can help retrieve the required packets.

Notice

The most common reason for those interruptions are caused by the operation system schedulers minimum time for switching between tasks. On Windows® systems the switching between two tasks takes around 15 ms. This can be enough to fill the packet queues of the system so that packets are dropped or missed.

1.6 Resend Algorithm – Network Advice

In theory, 10 GigE is capable of a maximum bandwidth of 10 Gbit/s. The GigE Vision Standard utilizes the UDP protocol which allows 100 % exploitation of the available network bandwidth without reserving capacity for required packet resend.

For any packet resend operation if required, the Baumer GAPI requires some bandwidth to be available. It is recommend to consume not more than 95% of the maximum bandwidth for system and camera configuration to ensure there is enough capacity left for any necessary packet resend.

There are several configuration options to reduce the maximum bandwidth:

- Reduce frame rate (fps) (e.g. AcquisitionFrameRate, AcquisitionFrameRateEnable)
- Reduce frame size (e.g. ROI, binning etc.) to get higher frame rates at reduced bandwidth
- Choose a smaller pixel format e.g. Mono8 instead of Mono12 to achieve higher frame-rates at similar bandwidth

It is also a good idea to set a packet delay (GevSCPD) to introduce small gaps between packets (see figure 2). This will spread the data of one image out and can help the system to process the data as it arrives at a slower but steady rate.




Figure 2: Flow of packets with and without a set Packet Delay (GevSCPD)

Notice

Calculation example, Packet Delay

A 10 GigE Network provides a bandwidth of 10 Gbit/s which equals 10bit/ns. If the Packet size is set to 9000 byte (72000 bit) one packet will need around 7200 ns to be sent.

To introduce a 10 % gap between each packet GevSCPD would therefore be set to 720 ns

Attention: Different camera models might use different units for the GevSCPD parameter, please refer to the technical data sheet for more information.

1.7 Resend Algorithm – Configuration

The Baumer resend algorithm is responsible to re-transfer packets which were not received correctly. Quite often packets are dropped if the system is temporarily unable to process packets at the required rate during a spike in processing activity. There are a few parameters to configure the algorithm, the ideal values depend on the overall system and its performance. All parameters can be configured in the bsysgige.xml file.





Figure 3: Necessary minimum packet queue

The diagram above shows the necessary minimum packet queue depth for 1 GigE and 10 GigE in order for the system to be able to temporarily store enough incoming packets during one or two scheduler switches so they can be safely retrieved once the receiving thread is activated again by the scheduler. If the product out of ResendRetryThreshold and MaxResendPerPacket falls below the line, packets will be lost in the given situation.

ResendRetryThreshold – As there might be a queue of packets waiting to be processed by the system a requested resend-packet will be queued at the end and cannot be confirmed as arrived immediately. The ResendRetryThreshold parameter sets the number of packets the system should wait until it is requested again or finally given up on. It is typically a good idea to wait a little bit before requesting a resend to allow the system to recover before giving any additional work to do.

Notice

Each camera has a hard limit, how many packet and/or images can be kept in memory to be resent if necessary. Therefore it is important to keep the abilities of the actual camera in mind as a very high ResendRetryThreshold can mean that the camera is no longer able to provide the requested packet.

MaxResendsPerPacket – This parameter specifies how often a packet can be requested for resend before giving up. A high value increases the chance to recover a packet but will lead to a higher system load as lost packets might be requested over and over again.

In case the system does produce incomplete images the ResendRetryThreshold can be raised until no more incomplete images are received. If that doesn't help the MaxResendsPerPacket should be raised to see if a stable transfer can be reached.

Notice

The product of ResendRetryThreshold and MaxResendsPerPacket must always be smaller than the packet queue. Therefore you need to adjust the FilterDriverBufferCount and the StreamSocketSize accordingly.

Notice**Calculation example, resend parameters**

How many packets are generated during a scheduler switch?

1 GBit/s = 125 kByte/ms, at MTU size of 9000kbyte that are 13,888 Packets/ms
→ during 15,6ms scheduler switching 216 packets are generated

10 GBit/s = 1,25 Mbyte/ms at MTU size of 9000kbyte that are 138,88 Packets/ms
→ during 15,6ms scheduler switching 2167 packets are generated

Calculation of the resend parameters depending on the required packet queue depth:

$$PQD = MRPP * RRT$$

*PQD = PacketQueueDepth – The depth of the packet queue

*MRPP = MaxResendPerPacket – Sets how often a package can be resent until giving up, raising it can produce additional network load.

*RRT = ResendRetryThreshold – Sets the time until a resent is first requested, raising it can introduce latency while retrieving the images

1.8 Further Configuration and Optimization

Below we have collected some measurements to be taken in order to increase system performance and stability.

Windows

- Check the Task Manager for running processes, try to disable or stop any unnecessary process. Even if a process is idle at the moment it might produce bursts of activity at some event or scheduled time and thereby reduce the performance of the system.
- Check the Task Manager for running services, again try to disable or stop anything unnecessary.
- Especially Antivirus software or Indexing systems can reduce the overall performance of a windows system.

General Network Optimization

- Please refer to the Baumer Application Note for general GigE configuration suggestions:
AN201622_Baumer_Application_Note_GigE-Adapter-Settings_vxx_EN.pdf
- Check if the 10GigE adapter is on the Baumer compliance list (others might work but are not tested for possible issues).
- Install the most recent Baumer Filter Driver if not done already.
- Check the 10GigE network adapter if the Baumer Filter Driver is selected.
- Check the 10GigE network adapter and remove any other Protocols or Services not needed.

2 Related Topics

Baumer Application Note for general GigE configuration suggestions:

AN201622_Baumer_Application_Note_GigE-Adapter-Settings_vxx_EN.pdf

3 Support

Please contact our Technical & Application Support Center with any questions.

Worldwide

Baumer Optronic GmbH

Badstrasse 30 · DE-01454 Radeberg

Deutschland

Phone +49 3528 4386 845

support.cameras@baumer.com

4 Legal information

All product and company names mentioned are trademarks or registered trademarks of their respective owners.

All rights reserved. Reproduction of this document in whole or in part is only permitted with previous written consent from Baumer Optronic GmbH.

Revisions in the course of technical progress and errors reserved.

Baumer Group

The Baumer Group is one of the worldwide leading manufacturers of sensors, encoders, measuring instruments and components for automated image processing. Baumer combines innovative technologies and customer-oriented service into intelligent solutions for factory and process automation and offers an unrivalled wide technology and product portfolio. With around 2,600 employees and 38 subsidiaries in 19 countries, the family-owned group of companies is always close to the customer. Baumer provides clients in most diverse industries with vital benefits and measurable added value by worldwide consistent high quality standards and outstanding innovative potential. Learn more at www.baumer.com on the internet.

**Baumer Optronik GmbH**

Badstrasse 30 · DE-01454 Radeberg
Phone +49 3528 4386 0 · Fax +49 3528 4386 86
sales@baumeroptronic.com · www.baumer.com